


IT6100B Series SCPI

**High Resolution and High Speed
Programmable Power DC Supply
Models IT6100B Series**



© Copyright 2005 All Rights Reserved
Ver2.0/MAR, 2016/ IT6100-508

Directory

About your safety.....	3
Certification and Warranty.....	3
Chapter 1 Remote Operation Mode.....	4
1.1 RS232 interface.....	4
1.2 USB interface.....	5
1.3 GPIB interface	6
1.4 Communication protocol	6
Chapter 2 Communication Order for IT6100B	7
2.1 IEEE488.2 Common Order.....	7
2.2 SCPI Essential Order	7
2.3 Output Order.....	7
2.4 Port Configure Order	8
2.5 Trigger Order	9
Chapter 3 SCPI Condition Register.....	10
Chapter 4 SCPI Order Description.....	12
4.1 IEEE488.2 Common Order.....	12
4.2 SCPI Essential Order	15
4.3 Output Order.....	18
4.4 Input measurement order	22
4.5 Trigger order	24

About your safety

Please review the following safety precautions before operating our equipment.

General information

The following safety precautions should be observed before using this product and any associated instrumentations. Although some instruments and accessories would be used with non-hazardous voltages, there are situations where hazardous conditions may be present. This product is intended for use by qualified personnel who recognize shock hazards and are familiar with the safety precautions required to avoid possible injury. Read and follow all installation, operation, and maintenance information carefully before using the product. Refer to this manual for complete product specifications.

If the product is used in a manner not specified, the protection provided by the product may be impaired. Before performing any maintenance, disconnect the line cord and all test cables.

Protection from electric shock

Operators of this instrument must be protected from electric shock at all times. The responsible body must ensure that operators are prevented access and/or insulated from every connection point. In some cases, connections must be exposed to potential human contact. Product operators in these circumstances must be trained to protect themselves from the risk of electric shock. If the circuit is capable of operating at or above 1000 volts, no conductive part of the circuit may be exposed.

Definition of users

Responsible body is the individual or group responsible for the use and maintenance of equipment is operated within its specifications and operating limits, and for ensuring that operators are adequately trained.

Operators use the product for its intended function. They must be trained in electrical safety procedures and proper use of the instrument. They must be protected from electric shock and contact with hazardous live circuits.

Service is only to be performed by qualified service personnel.

Safety symbols and terms

Connect it to safety earth ground using the wire recommended in the user manual.

The symbol on an instrument indicates that the user should refer to the operating instructions located in the manual.

High voltage danger

Certification and Warranty

Certification

We certify that this product met its published specifications at time of shipment from the factory.

Warranty

This instrument product is warranted against defects in material and workmanship for a period of one year from date of delivery. During the warranty period we will, at its option, either repair or replace products which prove to be defective. For warranty service, with the exception of warranty options,

this product must be returned to a service facility designated by us. Customer shall prepay shipping charges by (and shall pay all duty and taxes) for products returned to the supplier for warranty service.

Except for products returned to customer from another country, supplier shall pay for return of products to customer.

Chapter 1 Remote Operation Mode

IT6100B configure with three type of communication interface RS232 、 USB and GPIB for user adopting any of it flexible.

1.1 RS232 interface

There is a DB9 connector at the rear of the power supply, when connect to computer, you need to connect a cable with COM port on both side; active connection, you need to set the front panel composite press  (Shift) +  key configuration settings the same as computer configuration settings. RS-232 interface can be used to program all of the SCPI orders.

Note: RS232 settings must match the settings in front panel system information. If any change, please press  (Shift) +  key.

RS-232 data format

RS-232 data is a 10-bit word which has a start bit and a stop bit. The start bit and stop bit can not be edited. However, you can select the parity items with  (Shift) +  key on the front panel.

Parity options are stored in nonvolatile memory


Baud Rate

The front panel  (Shift) +  button allow the user to select a baud rate which is stored in the non-volatile memory: 4,800,960,019,200
3,840,057,600,115,200

RS-232 connection cable

Use a RS232 cable with DB-9 interface, RS-232 serial port can connect with the controller (eg PC). Do not use blank Modem cable. Below table shows the plug pins.

If your computer is using a RS-232 interface with DB-25 connector, you need a adapter cable with a DB-25 connector at one end and the other side is a DB-9(not blank modem cable)



RS-232 plug pins

Pin number	Description
1	No connection
2	TXD, transfer date
3	RXD, receive data
4	No connection
5	GND, ground
6	No connection
7	CTS, clear transfer
8	RTS, ready to transfer
9	No connection

RS-232 Troubleshooting:

If there is RS-232 connection problem, check the following:

Computer and power supply must configure the same baud rate, parity, data bits and flow control options. Note that the power configuration as a start bit and a stop bit (these values are fixed).

As described before in RS-232 connector, you must use the correct interface cable or adapter. Note that even if the cable has the right plug, the internal wiring may be wrong.

Interface cable must be connected to the correct serial port on the computer (COM1, COM2, etc.).

Communication Settings

Before communication, you should first make the following parameters of power supply and PC matches.

Baud Rate: 9600 (4800, 9600, 19200, 38400, 57600, 115200). You can enter the system menu from the front panel, and then set the baud rate.

Data bits: 8

Stop Bits: 1

Calibration (none, even, odd)

EVEN 8 data bits, have even parity

ODD 8 data bits have odd parity

NONE 8 data bits, no parity

Local Address: (0 ~ 31, the factory default setting is 0)

Parity=None	Start Bit	8 Data Bits	Stop Bit
-------------	-----------	-------------	----------

1.2 USB interface

Use a Cable with two USB port to connect the power and the computer. All power functions can be programmed via USB.

The USB488 interface functions of the power supply described as below:

- ◆ Interface is 488.2 USB488 interface.
- ◆ Interface receiver REN_CONTROL, GO_TO_LOCAL, and LOCAL_LOCKOUT request.
- ◆ Interface receives MsgID = TRIGGER USBTMC order information, and will pass TRIGGER order to the functional layer.

Power USB488 device functions described as follows:

- ◆ Devices can read all of the mandatory SCPI orders.
- ◆ Device is SR1 enabled.
- ◆ Device is RL1 enabled.
- ◆ Device is DT1 enabled

1.3 GPIB interface

First, Connect the GPIB interface on the power supply and the GPIB card on computer via IEEE488 bus, must be full access and tighten the screws. Then set the address, the address range of the power : 0 to 30, can set by the function key on the front panel, press the  (Shift)+ key to enter the system menu function, find the GPIB address setting by   button, type the address,  key to confirm. GPIB address is stored in nonvolatile memory line

1.4 Communication protocol

IT6100B programming should adopt SCPI communication protocol, please contact ITECH to get the protocol you need.

Chapter 2 Communication Order for IT6100B

2.1 IEEE488.2 Common Order

```
/*CLS  
/*ESE  
/*ESE?  
/*ESR?,  
/*IDN?,  
/*OPC,  
/*OPC?,  
/*PSC,  
/*PSC ? ,  
/*RST,  
/*SRE,  
/*SRE?,  
/*STB?,  
/*TRG,  
/*SAV ,  
/*RCL,
```

2.2 SCPI Essential Order

```
SYSTem  
:ERRor[:NEXT]?  
:VERSion?,  
:ADDRess?  
:REMote  
:LOCal  
:RWLock
```

```
STATus  
:QUEStionable  
[:EVENT]?  
:CONDition?  
:ENABLE <VALUE>  
:ENABLE?  
:OPERation  
:EVENT]?  
:CONDition?  
:ENABLE <VALUE>  
:ENABLE?
```

2.3 Output Order

```
OUTPut  
[:STATE] {<bool>}  
[:STATE]?  
:TImer  
[:STATE] {<bool>}  
[:STATE]?
```

```

:DATA {<timer>}
:DATA?
[SOURce:]
MODE {<FIXed|LIST|DRM>}
MODE?
VOLTage
[:LEVel] {<n>}
[:LEVel]?
:PROTection
    :STATe {<bool>}
    :STATe?
[:LEVel] {<n>}
[:LEVel]?
CURRent
[:LEVel] {<n>}
[:LEVel]?
LIST
:MODE {<mode>}
:MODE?
:STEP {<step>}
:STEP?
:COUNt {<n>}
:COUNt?
:CURRent
[:LEVel] {<n>,<n>}
[:LEVel]? {<n>}
:VOLTage
[:LEVel] {<n>,<n>}
[:LEVel]? {<n>}
:WIDth {<n>,<n>}
:WIDth? {<n>}
:NAME {<string code>}
:NAME?
:AREA {1|2|4|8}
:AREA?
:SAVe {1|2|3|4|5|6|7||8}
:RCL {1|2|3|4|5|6|7|8}
Input Meaaure Order
MEASure
[:SCALar]
:VOLTage[:DC]?
:CURRent[:DC]?
:POWer[:DC]?
:DVM[:DC] ?
:RESistance[DC]?

```

2.4 Port Configure Order

```

[SOURce:]
SYSTem
: SENSe [:STATe] {<bool>}

```

```
[{:STATe}]?
  PORT
    :MODE {<TRIGger|RIDFi|DIGital>}
    :MODE?

  RI
    :MODE {<OFF|LATChing|LIVE>}
    :MODE?

  DFI
    :SOURce {<OFF|QUES|OPER|ESB|RQS>}
    :SOURce?

  DIGital
    :OUTPut[:STATe] {<bool>}
    :INPut[:STATe]?
```

2.5 Trigger Order

```
TRIGger
[{:IMMEDIATE}]
:SOURce {<source>}
```


Chapter 3 SCPI Condition Register

You can get the condition of power supply and read parameter from the operation register. The power supply can get the different state by 4 condition registers. These registers are status byte register, standard event register, quest condition register and operation status register. The status byte register stores the information of 3 other register. You can get each register's meaning from the following table:


BIT	Signal	Meaning
0	CAL	Operation status register
1	WTG	The power supply is calculating new calibration parameter.
2	CV	The power supply is waiting for trigger signal.
3	CC	The power supply is in constant voltage condition.
4	RI	The power supply is in constant current condition. Show the input level condition of RI
0	OV	Quest condition register
1	OT	Over voltage
2	UNR	Over temperature The output of power supply is unregulated.
0	OPC	Standard event status register
2	QYE	Operation of power supply is completed.
3	DDE	Query error. Data of output array is missing.
4	EXE	Device-dependent error. Data stored in register is missing or error occurs in preliminary checkout.
5	CME	Execution error. Order parameter overflows or the condition is not right. Command error. Syntax or semantic error occurs when receiving information.
7	PON	Power on. It is 1when power supply is reset.
3	QUES	Status byte register If a quest enable condition changes, QUES is 1.
5	ESB	If a standard event status enable register changes, ESB is 1.
6	MSS	
7	RQS	
	OPER	If a operation event enable register changes, OPER is 1.

Structure of condition register as following:


Quest condition register




Operation event register



Status byte register



Standard event status register



Chapter 4 SCPI Order Description

4.1 IEEE488.2 Common Order

*CLS

This order can clean the register as follows:

Standard event status register

Quest condition register

Operation event register

Status byte register

Error code

Order syntax : ***CLS**

Parameter : None

*ESE

This order can set the parameter of standard event enable register. Setting parameter can determine which bit value of standard event register is 1 and the byte will enable ESB of status byte register is 1.

Order syntax : ***ESE <NRf>**

Parameter : 0~255

Reset value : Consult *PSC order

Example : *ESE 128

Quest syntax : ***ESE ?**

Return parameter : <NR1>

Reference order : ***ESR ? *PSC *STB ?**

Bit determination of standard event status enable register

Bit position	7	6	5	4	3	2	1	0
Bit Name	PON N	Not used	CME	EXE	DDE	QYE	Not used	OPC
Bit Weight	128		32	16	8	4		
PON	Power-on			DDE	Device-dependent error			
CME	Command error			QYE	Query error			
EXE	Execution error			OPC	Operation complete			

*ESR?

This order can read the value of standard event status register. After executing this order, standard event status register is reset. Bit definition of standard event status register is as the same as the standard event status enable register.

Quest syntax : ***ESR ?**

Parameter : None

Return parameter : <NR1>

Reference order : *CLS *ESE *ESE ? *OPC

***IDN?**

This order can read information about power supply. The parameter it returns contains 4 segments divided by comma.

Quest syntax : *IDN ?

Parameter : None

Return parameter : <AARD>	segment	description
	ITECH	manufacturer
	XXXX	product mode
	XXXXXX	product serial number
	VX . XX	software version number

For example : ITECH , 6152 , 000004 , V1.01

***OPC**

When all orders before this order are executed, OPC is 1 of the standard event status register.

Order syntax : *OPC

Parameter : None

Quest syntax : *OPC ?

Return parameter : <NR1>

***PSC**

This order control if power supply send a query or not when it is reset.

1 OR ON : When power supply is reset, operation event enable register, query event enable register and standard event status register are all reset.

0 OR OFF : The data of status byte register, operation event enable register, quest event enable register and standard event status enable register is stored in nonvolatile register, and is recalled when power supply is reset.

Order syntax : *PSC <bool>

Parameter : 0|1|ON|OFF

Quest syntax : *PSC ?

Return parameter : 0|1

Reference order : *ESE *SRE STAT:OPER:ENAB STAT:QUES:ENAB

***RST**

This order reset the power supply to default setting.

CAL:SEC:STAT OFF	OUTP OFF	CURR MAX	
VOLT:PROT MAX OFF	VOLT MIN PORT:MODE TRIG	TRIG:SOUR BUS RI:MODE OFF	SYST:SENS
DFI:SOUR OFF	VOLT:PROT:STAT OFF		

Order syntax : *RST>

Parameter : None

***SRE**

This order can set the parameter of standard event register. Setting parameter can determine which byte value of status byte register is 1 and the byte will enable RQS of status byte register is 1. Bit definition of status byte enable register is as the same as the status byte register.

Order syntax : ***SRE <NRf>**

Parameter : 0~255

Reset value : Consult *PSC order

Example : *SRE 128

Quest syntax: ***SRE ?**

Return parameter : <NR1>

Reference Order : ***ESE *ESR ? *PSC *STB ?**

***STB?**

This order can read the data from status byte register. After executing this order, status byte register is reset.

Quest syntax : ***STB ?**

Parameter : None

Return parameter : <NR1>

Reference order : ***CLS *ESE *ESR**

Bit determination of standard event status enable register

Bit Position	7	6	5	4	3	2	1	0
Bit Name	OPER	RQS	ESB	no use	QUES	no use	no use	no use
Bit Value	128	64	32		8			

***TRG**

When power supply's trigger source is a order, this order will give a trigger signal. And it's function is as the same as the function of **[SYStem:]TRIGger** order.

Order syntax : ***TRG**

Parameter : None

Reference order : **TRIG TRIG:SORU**

***SAV**

This order can save the parameters of power supply to register. These parameter contains constant current, constant voltage, maximum voltage value and step voltage value.

Order syntax : ***SAV<NRf>**

Parameter : 1~50

Example : ***SAV 3**

Reference order : *RCL

*RCL

This order can recall the parameter you saved before from the register.

Order syntax : *RCL<NRf>

Parameter : 1~50

Example : *RCL 3

Reference order : *SAV

4.2 SCPI Essential Order

SYSTem:ERRor[:NEXT]?

This order can get the error code and error information of the power supply.

No error

(1)	Too many numeric suffices in Command Spec
(10)	No Input Command to parse
(14)	Numeric suffix is invalid value
(16)	Invalid value in numeric or channel list, e.g. out of range
(17)	Invalid number of dimensions in a channel list
(20)	Parameter of type Numeric Value overflowed its storage
(30)	Wrong units for parameter
(40)	Wrong type of parameter(s)
(50)	Wrong number of parameters
(60)	Unmatched quotation mark (single/double) in parameters
(65)	Unmatched bracket
(70)	Command keywords were not recognized
(80)	No entry in list to retrieve (number list or channel list)
(90)	Too many dimensions in entry to be returned in parameters
(101)	Command Execution error
(100)	Too many command
(110)	Rxd error Parity
	Error EEPROM
	Config data error
	Error Calibration data
	Factory Data error

Order syntax : SYST:ERR?

Parameter : None

Return parameter : <NR1> , <SRD>

SYSTem:VERSion?

This order can query the software version.

Order syntax : SYST:VERS?

Parameter : None

Return parameter : <NR2>

SYSTem:REMote

This order can set SOURCE METER as remote control mode.

Order syntax : **SYST:REM**

Parameter : None

Quest syntax : None

SYSTem:LOCal

This order can set SOURCE METER as panel control mode.

Order syntax : **SYST:LOC**

Parameter : None

Query syntax : None

SYSTem:RWLock[:STATE]

This order can set LOCAL key of SOURCE METER enable or not.

Order syntax : **SYST:RWL**

STATus:QUEStionable[:EVENT?]

This order can read the parameter from quest event register. After executing , quest event register is reset.

Quest syntax : **STATus:QUEStionable[:EVENT?]**

Parameter : None

Return parameter : <NR1>

Reference order : **STATus:QUEStionable:ENABLE**

Bit determination of standard event status enable register

Bit Position	7	6	5	4	3	2	1	0
Bit name	no use	unr	OT	OV				
Bit Value						4	2	1

STATus:QUEStionable:CONDition?

This order can read the parameter from quest condition register. When a bit of quest condition changes, the bit value corresponding in quest event register is 1.

Quest syntax : **STATus:QUEStionable: CONDition?**

Parameter : None

Return parameter : <NR1>

STATus:QUEStionable:ENABLE

This order can set the parameter of quest event enable register. Setting parameter can determine which bit value of quest event register is 1 and the bit will enable QUES of status byte register is 1.

Order syntax : **STATus:QUEStionable:ENABLE <NRf>**

Parameter : 0~255

Reset value : Consult *PSC order

Example : **STATus:QUEStionable:ENABLE** 128

Quest syntax : **STATus:QUEStionable:ENABLE ?**

Return parameter : <NR1>

Reference order : ***PSC**

STATus:OPERation:EVENt]?

This order can read the parameter from operation event register. After executing this order, operation event register is reset.

Quest syntax : **STATus: OPERation [:EVENt]?**

Parameter : None

Return parameter : <NR1>

Reference order : **STATus: OPERation:ENABLE**

Bit determination of standard event status enable register

Bit Position	7	6	5	4	3	2	1	0
Bit Name	no use	no use	no use	RI	CC	CV	WTG	CAL
Bit value				16	8	4	2	1

STATus:OPERation:CONDition?

This order can read the parameter from the operation condition. When the parameter of operation condition register changes, the bit corresponding in operation event register is 1.

Quest syntax : **STATus: OPERation: CONDITION?**

Parameter : None

Return parameter : <NR1>

STATus:OPERation:ENABLE

This order can set the parameter of operation even enable register. Setting parameter can determine which bit value of operation event register is 1 and the bit will enable OPER of status byte register is 1.

Order syntax : **STATus: OPERation:ENABLE** <NRf>

Parameter : 0~255

Reset value : Consult *PSC order

Example : **STATus: OPERation:ENABLE** 128

Quest syntax : **STATus: OPERation:ENABLE ?**

Return parameter : <NR1>

Reference order : ***PSC**

4.3 Output Order

OUTPut[:STATe]

This order can set power supply output on or off.

Order syntax : **OUTPut[:STATe] <bool>**

Parameter : 0|1|ON|OFF

*RST value : OFF

Quest syntax : **OUTPut:STATe?**

Return parameter : 0|1

OUTPut:TIMer[:STATe]

This order can set output timer's state of power supply.

Order syntax : **OUTPut:TIMer[:STATe] <bool>**

Parameter : 0|1|ON|OFF

*RST value : OFF

Quest syntax : **OUTPut:TIMer:STATe?**

Return parameter : 0|1

OUTPut:TIMer:DATA

This order can set the time of output timer.

Order syntax : **OUTPut:TIMer:DATA <NR1>**

Parameter : <NR2>

*RST value : 1

Quest syntax : **OUTPut:TIMer:DATA?**

Return parameter : <NR2>

FUNCtion:MODE

This order can set the power supply working in order fixed mode or list mode.

FIXed Order fixed mode

LIST List mode

DRM Digital milliohm meter

Order syntax : **FUNCtion:MODE <mode>**

Parameter : FIXed|LIST|DRM

*RST value: FIXed

Example : **FUNCtion:MODE FIX**

Quest syntax : **FUNCtion:MODE ?**

Return parameter : <CRD>

[SOURce:]CURRent [:LEVel]

This order can set current value of power supply.

Order syntax : **[SOURce:]CURRent [:LEVel] <NRf>**

Parameter : MIN TO MAX|MIN|MAX

Unit : A mA

*RST value: MIN

Example : **CURR 3A , CURR 30mA , CURR MAX , CURR MIN**

Quest syntax : **[SOURce:]CURREnt [:LEVel] ?**

Parameter : [MIN|MAX]

Example : **CURR ? , CURR ? MAX, CURR ? MIN**

Return parameter : <NR2>

[SOURce:]VOLTage[:LEVel]

This order can set voltage value of power supply.

Order syntax : **[SOURce:]VOLTage[:LEVel] <NRf>**

Parameter : MIN TO MAX|MIN|MAX

Unit : V | mV| KV

*RST value : MAX

Quest syntax : **[SOURce:]VOLTage[:LEVel] ?**

Parameter : [MIN|MAX]

Return parameter : <NR2>

[SOURce:]VOLTage:PROTection:STATe

This order can set over voltage protection.

Order syntax : **[SOURce:] VOLTage:PROTection:STATe <bool>**

Parameter : 0 | 1 | ON | OFF

Unit: None

*RST value : OFF

Example : **VOLT:PROT : STAT 1, VOLT :PROT:STAT ON**

Quest syntax : **[SOURce:] VOLTage:PROTection:STATe ?**

Parameter : None

Example : **VOLT:PROT:STAT ?**

Return parameter : <0 | 1>

[SOURce:]VOLTage:PROTection[:LEVel]

This order can set voltage protection maximum level.

Order syntax : **[SOURce:] VOLTage:PROTection[:LEVel] <NRf>**

Parameter : MIN TO MAX|MIN|MAX

Unit : V mV

*RST value : MAX

Example : **VOLT:PROT 30V, VOLT PROT MAX**

Quest syntax : **[SOURce:] VOLTage:PROTection[:LEVel] ?**

Parameter : [MIN|MAX]

Example : **VOLT:PROT?** , **VOLT PROT ?** MAX

Return parameter : <NR2>

[SOURce:]LIST:MODE

This order can set list file .

CONTinuous List operation is continuous mode.

STEP List operation is step mode.

Order syntax : **[SOURce:]LIST:MODE <CRD>**

Parameter : CONTinuous|STEP

Quest syntax : **[SOURce:]LIST:MODE ?**

Return parameter : <CRD>

[SOURce:]LIST:STEP

This order can set operation mode of list file.

ONCE List operate once

REPeat Repeat list operation

Order syntax : **[SOURce:]LIST:STEP <SRD>**

Parameter: ONCE|REPeat

Quest syntax : **[SOURce:]LIST:STEP ?**

Return parameter : <CRD>

[SOURce:]LIST:COUNt

This order can set the steps of list operation.

Order syntax : **[SOURce:]LIST:COUNt <NRf>**

Parameter : 2~400

Quest syntax : **[[SOURce:]LIST:COUNt ?**

Parameter : None

Return parameter : <NR1>

[SOURce:]LIST :CURRent[:LEVel]

This order can set current step.

Order syntax : **[SOURce:]LIST :CURRent[:LEVel] <NRf>**

Parameter : 0~30A

Unit : A |mA

Example : **LIST:CURR 1 , 3A ;**

Quest syntax : **[SOURce:]TRANSition:CURRent:TLEVel ?**

Parameter : None

Example : **LIST:CURR ? 1 ;**

Return parameter : <NR2>

[SOURce:]LIST :VOLTage[:LEVel]

This order can set voltage step.

Order syntax : **[SOURce:]LIST : VOLTage [:LEVel] <NRf>**

Parameter : 0~360V

Unit : V mV

Example : **LIST:VOLT 1 , 3V ;**

Quest syntax : **[SOURce:]TRANSition: VOLTage:TLEVel ?**

Parameter : None

Example : **LIST:VOLT ? 1 ;**

Return parameter : <NR2>

[SOURce:]LIST:WIDth

This order can set the minimum step time.

Order syntax : **[SOURce:]LIST:WIDth <NRf>**

Parameter : MIN TO MAX|MIN|MAX

Unit : S mS

Example : **LIST:WID 1, 100mS;**

Quest syntax : **[SOURce:]LIST:WIDth ?**

Parameter : None

Example : **LIST:WID? 1;**

Return parameter : <NR2>

[SOURce:]LIST:NAME

This order can set name for list file. Make sure that the file name should less than 8 characters.

Order syntax : **[SOURce:]LIST:NAME <name>**

Parameter : <SRD>

Example : **LIST:NAME 'TEST';**

Quest syntax : **[SOURce:]LIST:NAME?**

Return parameter : <SRD>

[SOURce:]LIST:SAVe

This order can save list file into register.

Order syntax : **[SOURce:]LIST:SAVe <NR1>**

Parameter : 1~8

Example : **LIST:SAV 1**

[SOURce:]LIST:RCL

This order can recall the list file saved before from the register.

Order syntax : **[SOURce:]LIST:RCL <NR1>**

Parameter : 1~8

Example : LIST:RCL 1

4.4 Input measurement order

MEASure[:SCALar]:VOLTage[:DC]?

This order can get the input voltage of power supply.

Order syntax : **MEASure[:SCALar]:VOLTage[:DC]?**

Parameter : None

Return parameter : <NR2>

Return parameter unit : V

Example : **MEAS:VOLT ?**

MEASure[:SCALar]:CURREnt[:DC]?

This order can get the input current of power supply.

Order syntax : **MEASure[:SCALar]:CURREnt[:DC]?**

Parameter : None

Return parameter : <NR2>

Return parameter unit : A

Example : **MEAS:CURR ?**

MEASure[:SCALar]:DVM[:DC]?

This order can get voltage value from the digital voltage meter.

Order syntax : **MEASure[:SCALar]:DVM?**

Parameter : None

Return parameter : <NR2>

Return parameter unit : V

Example : **MEAS:DVM?**

MEASure[:SCALar]:RESistance[:DC]?

This order can read the resistance value from the milliohm meter.

Order syntax : **MEASure[:SCALar]: RESistance?**

Parameter : None

Return parameter : <NR2>

Return parameter unit : R

Example : **MEAS:RES?**

Interface Configure Order

[SOURce:]SYSTem:SENSe [:STATe]{<bool>}

This order can control the power supply enable remote sense function or not.

Order syntax : **SYSTem: SENSe [:STATe] <bool>**

Parameter : 0|1|ON|OFF

Quest syntax : **SYSTem:SENSe [:STATe] ?**

*RST value : 0

OUTPut:PORT:MODE

This order can set port function of rear panel.:

TRIGGER function: Pin1、 pin2 can be used as the external trigger source of power supply and control list operation.

RI/DFI function : Inhibit Input can control the output state of power supply. Fault Output can shows false.。

DIGITAL I/O function : It can read and control output port state by order.

Order syntax : **OUTPut:PORT:MODE**

Parameter : TRIGger|RIDI|DIGital

Quest syntax : **OUTPut:PORT:MODE ?**

*RST value : TRIGger

OUTPut:RI:MODE

This order can set input mode of RI.

LITCHING mode : When the level of RI port changes from high to low, the output of power supply is off.

LIVE node : The output state of power supply changes along with the level of RI port. If the level of RI is high, the output is on; and the level of RI is low, the output of power supply is off.

OFF mode : The level state of RI do not affect the output state of power supply.

Order syntax : **OUTPut:RI:MODE**

Parameter : OFF|LATChing|LIVE

Quest syntax : **OUTPut:RI:MODE ?**

*RST value : OFF

OUTPut:DFI:SOURce

This order can set output source of DFI.

LITCHING mode : When the level of RI port changes from high to low, the output of power supply is off.

LIVE node : The output state of power supply changes along with the level of RI port. If the level of RI is high, the output is on; and the level of RI is low, the output of power supply is off.

OFF mode : The level state of RI do not affect the output state of power supply.

Order syntax : **OUTPut:DFI:SOURce**

Parameter : OFF|QUES|OPER|ESB|RQS

Quest syntax : **OUTPut:DFI:SOURce ?**

*RST value : OFF

[SOURce:]DIGItal:OUTPut[:STATe]

This order can set the output state of port. When the mode of port is DIGITAL, this order is enable.

Order syntax : **SOURce:OUTPut[:STATe]**

Parameter : OFF|ON|0|1

[SOURce:]DIGItal:INPut[:STATe]

This order can set the input state of port. When the mode of port is DIGITAL, this order is enable.

Order syntax : **SOURce:INPut[:STATe] ?**

4.5 Trigger order

TRIGger[:IMMEDIATE]

When trigger source is order mode, this order will give a trigger signal. And its function is as the same as *TRG order.

Order syntax : **TRIGger[:IMMEDIATE]**

Parameter : None

Reference order : **TRIG TRIG:SORU**

TRIGger:SOURce

This order can set the trigger mode of power supply.

IMMEDIATE: If this function is enabled, press **Shift** + **Trigger**, the power supply will start trigger operation once.

EXTernal: External trigger signal (TTL). There is a trigger input port on the rear panel. When this function is enabled, please give this trigger input port a pulse about 5 mS, and the power supply will start trigger operation once.

Bus: Order trigger mode. When this function is enabled, and the power supply receives order *TRG or TRIGGER, the power supply will start trigger operation once.

Order syntax : **TRIGger:SOURce <mode>**

Parameter : IMMEDIATE|EXTernal|BUS

*RST value: KEY